

**STEP 1:** Verify with manufacturer the exterior coating applied to equipment purchased. RAL number or color code required for match.

**STEP 2:** Confirm filter system is off-line and contents are **NOT** under pressure.

**STEP 3:** Ensure surface area is dry and free of moisture. Let tank dry completely before preparation.

**STEP 4:** Using a wire brush and sand paper, gently prepare area of concern. Removing loose material and prepping 3-4" around affected area.

**STEP 5:** Prepare coating, and mix to manufacturers recommendations.  
*(some may be in powder form and others may come in an aerosol can).*

**STEP 6:** Using a brush, apply epoxy to desired area.  
*(aerosol can applications will require spraying from can).*

**STEP 7:** Allow 24-48 hrs before adding media or water back into tank.

**STEP 8:** Slowly fill tanks with water and resume operation.



## FUZE COATED EXTERIOR TOUCH UP INSTRUCTIONS