

STEP 1: Confirm filter system is off-line and contents are **NOT** under pressure.

STEP 2: Locate top media fill port, remove bolts and hardware.
Remove coupling clamps, fill port lid and hardware.

STEP 3: Locate media drain port, remove couplings, hardware and media drain port lid.

STEP 4: Prepare surface in affected area, using sand paper or other abrasive to clean any impurities until surface is smooth and clean.

STEP 5: Shake paint and mix according to provided mixture ratio and coverage.

STEP 6: Paint area as needed with supplied brush, let dry for 2-4 hrs once complete.

STEP 7: Reassemble gaskets, couplings, and hardware to original location and position.

STEP 8: Slowly fill tanks with with water and resume operation.



AG EXTERIOR TOUCH UP INSTRUCTIONS